


How to repair network problem after flashing sagem 300X/400X

If your phone after write flash no have network make repair step by step :

- 1 . Connect cable (C2/4) to SMTi box
- 2 . Connect phone to cable data connector
- 3 . Run latest SMTi EXE
- 4 . Click >**view log**< button



- 5 . You see txt log file with all operation
- 6 . Press (**Ctrl + F**) try serch your phone **IMEI**
- 7 . If you see log from **first flashing operation** for this phone

Write Flash:

POWER ON PHONE ...Ok!

v.rom :0411
hash :BE3F21AC2239C4CA60863D311E1737BA
dieid :2C1E0A7D8753049D

- Load Certificate ...Ok!
- Load Application ...Ok!

Read Phone Info ...Done

Found Phone, Phone Info:

- Phone Type :my400X
- Phone FW :LA5,BG: 200106 1904
- Phone HT :84 0E 01
- Phone IMEI :**358198001XXXXXX**
- Phone Code :00000000 (inactive)
- Prod. Code :252500802
- Board Type :m62+

- NOR Flash ID :0001 227E 2221 2201
- Chip [0] :AMD S29GL128NH/L 128Mbit

- **F5107** : **XX XX**

Write Flash Data ...

- 8 . Copy Filed 5107 (**XX XX**) to correct window on SMTi EXE



- 9 . Press >**Write Field**< button upload field to phone .
- 10 . Restart Phone insert correct simcard and all done ;-)

Sagmaster Team (21-05-2009)